

# Recommended Painting Practices

- 1/ Clean all surfaces with soap and water let air dry
- 2/ Prime all surfaces with primer #330003  
(Note: For best results, the primer works best if you add a few drops of the base colour you will be using on you model)
- 3/ Airbrush should be used with a #2 needle and tip to avoid “spitting and clogging”
- 4/ Air Pressure should be between 20-25 PSI. If using lower air pressure, reducer #330004 should be used.
- 5/ Paint will set up in 1hr. But it is recommended to wait 24hrs. before masking and applying a second colour.
- 6/ Avoid applying heavy coats. It is better to apply several light coats to avoid runs in the paint
- 7/ Paint will dry to a glossy decal ready surface.
- 8/ After decals have been applied seal them with flat finish #330005
- 9/ Clean up your airbrush with soap and hot water.

***MSDS data sheet available for down load on our web site.***